



# TIE-DOWN ARM EXTENSION KIT



**1.** Remove the two front non-slip rubber feet from the base. If holes already exist in the frame, move on to step five.




**2.** If there are no holes in the frame, on the front and back side of the front leg of the frame measure  $1\frac{1}{16}''$  (1.7 cm) from the top and  $1\frac{9}{16}''$  (4 cm) from the end and mark the location.



**3.** It is recommended that you use a center punch prior to drilling. Use a  $\frac{5}{16}$  (8mm) metal drill bit to drill out the marked locations. The holes on the front should be directly across from those on the back.


# TIE-DOWN ARM EXTENSION KIT



**4.** Clear all shavings from the area before inserting leg extensions.



**5.** Insert leg extensions with the eye bolt holes facing upwards and secure them in place by using the quick release retaining pins.



**6.** Insert the eye bolts securely into the provided holes.